



SMALL HOLE FLUID

GAMMAJUICE™

GammaJuice™

AN ECONOMICAL REPLACEMENT FOR YOUR CURRENT SMALL HOLE FLUID

SPECIAL FEATURES

Synthetic & Recyclable 

Reduces Splatter / No Sticky Residue

Same Quality As Brand Name Fluid

More Consistent Holes

Available In Concentrate Or Premixed



GLOBAL EDM
S U P P L I E S

EXCLUSIVELY MANUFACTURED IN USA



RECYCLE GAMMA JUICE WATER TO SAVE DISPOSAL COSTS RELATED TO THIS FLUID. IT CAN RUN THROUGH A RESIN DEIONIZING TANK WHICH YIELDS A BRIX READING OF THREE(3). THIS WATER CAN THEN BE USED AS THE BASE WATER FOR THE CONCENTRATE

MATERIAL SAFETY DATA

NET VOLUME 19L / 5 US Gal

| CERTIFICATE OF ANALYSIS | | PRECAUTIONS | DISPOSAL METHOD |
|--|-------------|---|---|
| FLASH POINT (°C / °F) | NONE | PRODUCT MAY IRRITATE EYES AND SKIN | DISPOSE OF WASTE AND EMPTY CONTAINER IN ACCORDANCE WITH LOCAL, STATE AND FEDERAL REGULATIONS. |
| VISCOSITY | N/A | | |
| SPECIFIC GRAVITY | 1.10 @ 20°C | WEAR SAFETY GLASSES AND PROTECTIVE GLOVES WHEN HANDLING | |
| DENSITY | N/A | | |
| FIRST-AID | | | |
| IN CASE OF CONTACT, FLUSH EYES AND SKIN WITH WATER FOR 15 MINUTES. IF IRRITATION PERSISTS : (EYES) SEEK MEDICAL ATTENTION (SKIN) SEEK MEDICAL ATTENTION IF REQUIRED | | | |

MIXING RATIO

- THREE(3) PARTS WATER TO ONE(1) PART CONCENTRATE
- THE OPTIMAL BRIX READING SHOULD BE A RANGE BETWEEN TEN(10) TO TWELVE(12) USING A REFRACTOMETER

* WORKS GREAT WITH CHARMILLES AND SODICK MACHINES

CORPORATE OFFICE-Global EDM Supplies Inc.
1111 Western Row Road, Mason, OH 45040

TEL ▶ 800.708.1345
FAX ▶ 513.701.0457

CONNECTICUT OFFICE-Global EDM Supplies, Inc.
411 John Downey Drive, New Britain, CT 06051

TEL ▶ 800.290.7573
FAX ▶ 800.211.8886